









PC

| | | |
|--|--|--|
| <p>Power (1)</p>  | <p>Network (2)</p>  | <p>Opt. Mouse and keyboard (USB) (3)</p>  |
|--|--|--|

PRINTER

| | | |
|--|--|--|
| <p>Power (4)</p>  | <p>Network (5)</p>  | <p>Cash drawer (6)</p>  |
|--|--|--|


CARD TERMINAL

| | | |
|--|--|--|
| <p>Power (7)</p>  | <p>Network (7)</p>  | |
|--|--|--|

CASH DRAWER

| | | |
|--|--|--|
| <p>Printer (6)</p>  | | |
|--|--|--|

SCANNER

| | | |
|---|--|--|
| <p>Computer (USB) (3)</p>  | | |
|---|--|--|


Turn the page to see connections ->

PC



- (1) – Plug in the computer with the power cord.
- (2) – Plug in the network/internet cable to the computer and your router.
- (3) – If needed connect the mouse, Keyboard, and/or scanner via the USB cable in the computer's USB ports.

PRINTER



- (4) – Plug in the printer with the power cord.
- (5) – Plug in the network/internet cable to the computer and your router.
- (6) - If you have a cash drawer, now connect it to the printer.

CARD TERMINAL



- (7) – Connect your network/internet cable to the (ETH) port, and the power cord to the card terminal dongle.

Turn the page to see cables and cords ->